



Pavron

*...a new generation
in paving protection*

It's an accepted fact today that a simple program of pavement protection can significantly extend the life of asphalt paving and save property owners money.

And there's no better way to protect asphalt pavement than with SWEPCO Pavron ... a new generation paving sealer designed to offer the most attractive price-performance ratio in the industry.

A simple application of SWEPCO Pavron helps protect pavement from water damage, frost damage, age hardening, erosion and deterioration from fuel and oil spillage.

Applied to new pavement, Pavron helps insure maximum life, as well as reducing maintenance costs and keeping pavement looking good longer. Used on older pavement, Pavron restores the look of new pavement and puts paved areas back on the maintenance track.



SWEPCO Pavron is the cost effective way to maintain asphalt pavement.

Superior, all season protection.

SWEPCO protects asphalt pavement year-round.

In winter, pavement sealed with Pavron suffers less freeze thaw damage. Because water is sealed out of small cracks, the traditional freeze-thaw deterioration doesn't take place.

In the rainy season, pavement sealed with Pavron channels water off the lot instead of allowing it to seep into the subgrade where it can cause chuck holes and other serious damage.

For lasting protection of all types of asphalt pavement . . .



SWEPCO Pavron is ideal for protecting all types of asphalt pavement ... parking areas, driveways, roads ... even runways.

PERFORMANCE

In the summer, pavement sealed with Pavron has greater resistance to the blazing sun. Pavron's superior formulation stands up longer to the deteriorating effects of hot summer sun.

Special resistance to solvents and chemicals.

Fuel and oil spillage can quickly deteriorate asphalt parking areas and maintenance bays. Pavron is resistant to most types of fuel and oil, even jet and alcohol fuels. It's also resistant to many chemicals, including de-icing chemicals and many acids.

Prolongs pavement life.

Because it protects asphalt pavement from the most common forms of deterioration, Pavron prolongs pavement life. Chuck holes caused by water seeping through small pavement cracks are a thing of the past. Unsightly cracks and freeze damage are prevented. Deterioration caused by solvent and chemical spillage and drippage is reduced. And erosion and general aging caused by solar radiation are significantly retarded.

Reduces maintenance cost as much as 60%.

Fewer chuck holes and cracks mean less maintenance. And well sealed pavement won't need periodic overlays like unmaintained asphalt pavement. That means lower overall pavement maintenance costs. As much as 60% lower!

Keeps pavement looking good.

Pavron keeps pavement looking good. This can be especially important for retail and service businesses because attractive paved areas mean improved image and more customers.

Easy, fast, convenient and inexpensive.

Pavron even saves money on application. It's so simple to apply it takes less labor. In fact, it's so simple to apply, your

Typical Maintenance Costs Per Sq Ft For Asphalt Paved Areas		
Year	Sealed With Pavron	Unsealed
New	\$.13 For Sealing	.00
2	.00	.01 For Annual Repairs
3	.00	.02 For Annual Repairs
4	.13 For Sealing	.03 For Annual Repairs
5	.00	.05 For Annual Repairs
6	.00	.06 For Annual Repairs
7	.13 For Sealing	.07 For Annual Repairs
8	.00	.62 For New Overlay
9	.00	.01 For Annual Repairs
10	.13 For Sealing	.02 For Annual Repairs
11	.00	.03 For Annual Repairs
12	.00	.05 For Annual Repairs
13	.13 For Sealing	.06 For Annual Repairs
14	.00	.07 For Annual Repairs
15	.00	.62 For New Overlay
TOTAL	\$ 0.65 per Sq Ft	\$1.72 per Sq Ft

SWEPCO Pavron can save up to 60% of the cost of pavement maintenance. The chart above demonstrates the cost advantages of performing light maintenance and sealing every three years versus the costs of progressive annual maintenance which includes crack and chuck hole repair for a six year period ending in a new asphalt overlay every seven years.

own handyman or temporary labor can get professional results. Critical parking areas are back in service sooner. No long delays for complicated application procedures.

Economical coverage rate.

Pavron's economical coverage rate and superior performance yield the best price-performance ratio in the industry.

Versatile.

Pavron is perfect for protecting any type of asphalt pavement. Parking lots. Driveways. Maintenance Bays. Bicycle, golf cart and walking paths. Loading docks. Fueling areas. Warehouse floors. Manufacturing areas. Anywhere asphalt pavement is used.

SWEPCO provides simplified step-by-step written instructions with each order.

Minimum Coverage Rates

Smooth, Dense Surface	1.00 gal. per 100 sq. ft. (0.41 liter/ m ²)
Medium Surface	1.25 gal. per 100 sq. ft. (0.51 liter/ m ²)
Rough, Porous Surface	1.50 gal. per 100 sq. ft. (0.61 liter/m ²)

Southwestern Petroleum Corporation

P.O. Box 961005 • Fort Worth, TX 76161-0005 • Phone: (800)877-9372 or (817)332-2336 • Fax: (817)877-4047 • Web: www.swepcousa.com
 Southwestern Petroleum Europe • Industrieweg 6 • B-2390 Oostmalle (Antwerp) Belgium • Phone: (32-3)312 31 41 • Fax: (32-3)311 72 77
 Southwestern Petroleum Canada • 87 West Drive • Brampton (Toronto), Ontario, Canada L6T 2J6 • Phone: (905)457-0511 • Fax: (905)457-0637