



Leak Stopper Emergency Leak Repair

Roof leaks always seem to occur at the worst time. But with SWEPACO Leak Stopper, you can be prepared to stop them before major damage or inconvenience occurs. Even in the pouring down rain.

Simply pour these specially processed mineral granules on the site of the leak and in just minutes, the leak is temporarily patched. Anyone can do it. The granules automatically follow the water to the site of the leak and, once found, begin expanding to plug the leak until permanent repairs can be undertaken by maintenance personnel. Nothing is more effective as an emergency leak repair material. And it's a lot cheaper than a service call by a roofing contractor. Keep it on hand for that "rainy day".



**Stops Flat Roof Leaks In Minutes
To Avoid Costly Interior Damage**

KEY FEATURES

- works even in pouring rain
- automatically follows water to the leak
- expands in minutes to clog leaks
- harmless to the environment
- fast and easy to use
- simple clean-up for permanent repairs
- available in convenient 50-pound (23-kg) pails

Just pour it on and the leaks are gone ...



Application is simple. Just sprinkle these amazing granules over the leaking roof area. In minutes, they work their way into the leak and clog it, stopping the leak until permanent repairs can be made in dry weather.



Roofing & Building Maintenance Products Technical Information & Specifications

Refer to Product Data Bulletin or Product Container Label for complete preparation, application and coverage rate information.

Leak Stopper

PURPOSE & DESCRIPTION

SWEPCO Leak Stopper is a unique product which is used to temporarily stop leaks on flat roofs even in the pouring rain. It is a specially processed natural mineral which is heavier than water and expands up to 15 times its dry volume upon wetting. Simply pour the granules over the area of a suspected leak and they will follow the water to the leak itself and then clog the leak upon expansion. Water absorption and resulting swelling occurs in minutes so leak stoppage is immediate. Depending upon conditions, SWEPCO Leak Stopper will shrink and re-expand upon drying and re-wetting for some time.

SUPERIOR PERFORMANCE

SWEPCO Leak Stopper stops flat roof leaks in minutes, so it is the perfect emergency roof patch material.

PHYSICAL PROPERTIES

- Totally natural mineral
- Non-polluting
- Won't burn or contribute to spread of flame
- Heavier than water
- Automatically seeks out leaks
- Expands immediately when wetted

PACKAGING

Available in 50-pound (23-kg) pails.

APPLICATION

Apply by sprinkling in a 1/4-inch (0.635-cm) blanket over the area of the suspected leak.

COVERAGE RATES

One pail covers approximately 100 square feet (9.29 m²) at 1/4-inch (0.635-cm) dry thickness.

CLEAN-UP

SWEPCO Leak Stopper must be completely removed from the leaking area before permanent repairs are made. Let dry completely and then sweep vigorously to remove and dispose of used material. Do not leave on roof as the material becomes extremely slippery when wet.

STORAGE

SWEPCO Leak Stopper must be stored tightly sealed and protected from moisture. Unopened containers have a shelf life of one year provided they are stored in a dry location and protected from temperature extremes.



Southwestern Petroleum Corporation

P.O. Box 961005 • Fort Worth, TX 76161-0005 • Phone: (800)877-9372 or (817)332-2336 • Fax: (817)877-4047 • Web: www.swepcousa.com
Southwestern Petroleum Europe • Industrieweg 6 • B-2390 Oostmalle (Antwerp) Belgium • Phone: (32-3)312 31 41 • Fax: (32-3)311 72 77
Southwestern Petroleum Canada • 87 West Drive • Brampton (Toronto), Ontario, Canada L6T 2J6 • Phone: (905)457-0511 • Fax: (905)457-0637